



MORRIS

KETTLE INSTRUCTION MANUAL



MODELS:

R20810WKC / R20811WKG

R20812WKR / R20813WKB

R20831WKK



Please read these instructions carefully before use in order to avoid damage due to incorrect use and to better understand the functions of this product.

Please pay particular attention to the safety guide.

If you pass the device on to a third party, these Operating Instructions must also be handed over. Please keep them for future references.

IMPORTANT SAFEGUARDS

When using your kettle, basic safety precautions should always be followed, including the following:

1. Before making use of this kettle make sure you have read all instructions carefully and thoroughly.
2. Close supervision is necessary when any appliance is used by or near children.
3. Before connecting the kettle, check whether the voltage indicated on the appliance (underside of kettle and base unit) corresponds with the mains voltage in your home. If this is not the case, contact your dealer and do not use the kettle.
4. Switch off and unplug from the outlet before filling, emptying, cleaning, or when not in use.
5. Do not overfill above the maximum level indication mark, as boiling water may be ejected. Fill with cold water only.
6. To prevent any risk of fire, do not operate this unit in the presence of explosive and/or flammable fumes, or materials, or near gas and electric burners or inside heated ovens.
7. Do not let the cord hang over the edge of a table or a counter. Do not let the cord touch any hot surface.
8. Never yank on the cord as this may damage the cord and leading to a risk of electric shock.
9. If the cord or plug is damaged, or after the appliance malfunctions or is dropped or damaged in any way, return the appliance to your nearest authorized service agent for examination, repair or adjustment.
10. Avoid touching the surface of the hot kettle, always use the handle and knobs.
11. To avoid possible steam damage, avoid facing directly the spout while operating the kettle.
12. If operated on wood furniture, use a protective pad to prevent damage on delicate finishes.
13. To avoid scalding, always ensure the lid is firmly closed before operation.

14. Scalding may occur if the lid is opened while boiling water.
15. Always handle the lid carefully when the unit is hot.
16. Extreme caution must be used when moving the kettle containing hot water. Never lift the kettle by its lid. Always use the body handle.
17. Do not switch the kettle on if it is empty.
18. To prevent any electrical hazard, do not immerse this kettle, power base or cord set in any liquid.
19. Use this kettle only along with the supplied base unit. Do not use the base unit for other purposes.
20. To prevent the risk of fire, do not operate in the presence of explosive and/or flammable materials.
21. During the boiling of water, or in the short time after the water boils, do not attempt to open the lid, as the steam might scald your hand.
22. Never exceed the maximum water volume, as there exists a risk of damaging the kettle.
23. Perform descaling of the kettle on a regular basis so as to maintain optimal operation of your kettle.
24. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
25. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children without supervision. Keep the appliance and the cord out of reach by children aged less than 8 years.
26. Children of less than 3 years should be kept away unless continuously supervised. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

Save these instructions for future reference

SPECIAL SAFEGUARDS for this device

- Stand the appliance on a table or flat surface.
- Do not use or keep this product outside when it is raining.
- Do not store the appliance near hot ovens or heating appliances.
- Certain parts of the appliance can get hot. Do not touch them, as you may burn yourself.
- Never modify the appliance in anyway.
- Use only cold water when filling the device.
- The water level must be between the MAX and MIN mark.
- Switch the device off before removing it from the base.
- Always ensure that the lid is tightly closed.
- The base and exterior of the kettle must not become wet.
- Make sure the body of the device matches with the base.

USE OF THE MACHINE

Before using the machine for the first time, rinse the inside with fresh water.

1. Fill half of the tank with fresh water.
2. Put the switch on "ON" position. The light turns on, showing that water begins heating up.
3. After boiling, the apparatus will turn off automatically
4. Raise the device body carefully and empty water in a sink by watching out not to splash (risk of scald).
5. The apparatus is ready to be used again.

WHILE USING

1. Put the electric charger base on a flat surface.
2. Fill the device with fresh water (without any additives).
Note: Do not overfill! Use the water level indicator.
3. Place the cover.
4. Place the device on its base.
5. Only connect the machine to a properly installed 220V~ 60Hz safety socket.
(check whether the electrical voltage that you intend to use is the same as that of the machine. Details are to be found on the label on the base).
6. Change the switch of the device to position "1". The control lamp on the device illuminates, showing that the water is heating.
7. While the water starts boiling, the device will turn off automatically.
8. Lift the device and pour the water in a safe container.
Note: Take care to avoid any burn. Do not press up the lid when pouring.

MAINTENANCE AND CLEANING

Before cleaning, switch off the device.

Always disconnect it and let it cool before cleaning.

Clean the outside of the device with a sponge or slightly wet linen.

Never immerse the body or the base of the device in water or any other liquid!

Do not use abrasive cleaners, gritting, or metal brush or another sharp object for cleaning.

STORAGE

- Ensure the unit is completely cool and dry.
- Do not wrap the cord around the appliance, as this will cause damage.
- Keep the appliance in a cool, dry place.

SPECIFICATIONS


Power supply AC 220-240V 50/60Hz
Power 1850-2200W

The characteristics may change without prior notice.

This unit is equipped with an electrical outlet with earth and must be earthed in the appropriate plug.

Note: In the event of question concerning the earth or electric connection, please consult a qualified personnel.

In the event of short-circuit, earthing reduces the risk of electric shock while making possible the current to be evacuated by the wire of ground.



CAUTION: In order to minimize the risks of electric shock, in case of a breakdown do not try to open the case but call a qualified technician for repairs.

NOTICE ABOUT RECYCLING



Your product is designed and manufactured with high quality materials and components which can be recycled and reused.

This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste. Please dispose of this equipment at your local community waste collection/ recycling centre.

In the European Union there are separate collection systems for used electrical and electronic products.

Please help us to conserve the environment we live in!

DECLARATION OF CONFORMITY

Herewith, Amiridis-Savvidis S.A. states that this product, complies with the requirements of below directives:

EMC-Directive: 14 / 30 / EU

Low Voltage Directive: 14 / 35 / EU

ErP Directive 09 / 125/ EC

CE Marking: 93 / 68 / EEC

RoHS Directive: 11 / 65 / EU & 15 / 863 / EU

The detailed declaration of conformity can be found at www.morris.gr



Exclusive importer in Greece:

Amiridis – Savvidis S.A.

87A, 17th Noemvriou str, P.C. 55534

Thessaloniki – Greece

T: +302310944944 | F: +302310944940

www.amiridis-savvidis.gr