



MORRIS

MHR-20044S

Please read this manual carefully before use this product

USER MANUAL


for Wi-Fi connection



NOTE: The environment that appears is indicative and may change to some upgrade as part of the ongoing improvement of this experience



Before connection:

1. Put the heater in a space with stable network.
2. Download the App "TUYA Smart" via below ways:


- Scan the QR code 

- Search "Tuya Smart" in App store
3. Open the App, press "Register" to create the account.

REGISTRATION TO THE APPLICATION


<ol style="list-style-type: none">1. Press 'Register' button to create a new account2. Press 'Agree' for Privacy Policy, to continue.	 A screenshot of the TUYA Smart app registration screen. It features a blue house icon with a Wi-Fi symbol inside a square. Below the icon is a white rounded button labeled "Register". At the bottom, there is a link for "Login with Existing Account".	 A screenshot of a "Privacy Policy" dialog box. The text states: "We pay high attention to the privacy of personal information. To fully present how we collect and use your personal information, we revised the Privacy Policy in detail in compliance with the latest laws and regulations. By clicking I Agree, you agree that you have fully read, understood, and accepted all the content of the revised Privacy Policy. Please take your time to read the Privacy Policy. If you have any questions, please contact us anytime." Below the text is a link for "Privacy Policy". At the bottom, there are two buttons: "Disagree" and "Agree". Below these buttons is a "Register" button and a "Login with Existing Account" link.
--	---	--

3. Enter your email or your mobile telephone number to get verification code and press 'Get verification Code'.



When you receive verification code, type it to the spaces and create a password before you press to confirm 'Done'.

Note: the verification code will be sent to you either at your mobile or at your email, depending on which registration way you chose in the beginning.



NETWORK SETTINGS


You can be connected to the App using one of these ways:

- Add manually, or
- Search by device

Before you begin network setting progress, make sure the device is as closer as it can be to the Wi-Fi router.

Introduction to connection mode

1. Insert the mains plug into a suitable wall outlet, turn on the mechanical on/off switch. Then the heater will enter into standby mode and the light on "Standby" (🔌) and "Timer" (🕒) buttons will turn on.
2. Press and hold the "Timer" button until you hear a BEEP (about 3 seconds), then the Wi-Fi icon begins to flash and the Wi-Fi function opens for first using. Then you may start the connection on APP.




Important Notice: Only 2.4GHz networks are supported.

Manual connection through "Add Manually" mode

1. Before you begin the connection procedure, make sure **the Wi-Fi** connection of the device is activated and that the Wi-Fi symbol on screen is blinkg rapidly.
2. If not press and hold the "Timer" button again for 3 seconds while checking that your mobile TA is connected Wi-Fi network.

When only Wi-Fi is opened - Manual connection through "Add Manually" mode


1. Enter the App, press button + (top right of the screen) and add you device by choosing the "Add Device" button.



2. Scroll through the screen by going to the "Add Manually" section.
3. In vertical menu on the left, select "Small Home Appliances".
4. Choose the device's type Heater.


Note 1: In case you have activated Bluetooth, the device will automatically appear on your screen as "Device to be added".

Note 2: The photo is just indicative, it is possible the category and/or the device's type to appear in another place of your screen.



Make sure the Wi-Fi indicator light flashes.

If not, press and hold the "Timer" button again for 3 seconds.



Select your Home Network, enter your password, press "Next" and "Confirm and proceed".

Reset and disconnect Wi-Fi

1. If the indicator is blinking, press "Confirm the indicator is blinking" and then select the corresponding status.
2. If you need to reset or disconnect Wi-Fi, press and hold the three buttons indicated below together for 5 seconds until the Wi-Fi icon begins to flash.



< Add Device

Enter Wi-Fi Password

Only 2.4 GHz Wi-Fi networks are supported

Wi-Fi Name [Change Network](#)

Password

Confirm

All settings will be transferred to your device.

Please wait till the connection with the device is successfully added.

If connection fails, try again.

If connection fails again, please check "Troubleshooting" chapter for further assistance.

Once the connection is done, the device will appear on your screen.

Press button "Done" to complete procedure.

< Add Device

Connecting...

Place your router, mobile phone, and device as close as possible

14%

- ✓ Device found
- ✓ Register Device to Smart Cloud
- Initializing device...

< Add Device

Device added successfully

Morris Heater

Done

Automatic connection through "Search for Device" mode

Before you begin the connection procedure, make sure the Wi-Fi connection of the device is activated and that the indicative light flashes.

When both Wi-Fi & Bluetooth are activated

1. Enter the App, press button + (top right of the screen) and add your device by choosing the **"Add Device"** button. Waiting about 15sec, the device picture will appear automatically. Press the button "Add" and selected the device to add.




2. Select your home network shown in the screen now. Enter your password, press "Next" and "Confirm and proceed", then it will start to search the device.

At this same network you must have connected your mobile also.

Important Notice:

Only 2.4GHz networks are supported.




At this point, begins searching / adding the device.


Once searching procedure is done, the device will appear on your screen as "available".




Press the "Next" button. When the connection procedure is complete, the device is shown as "Device added successfully".

Then press the "Done" button, the added device will be shown on the home page.



Device control environment



1. Press buttons '+' / '-' to increase / reduce temperature settings of the device (5-30°C) .
2. On your screen you can see both setting temperature and current temperature.
Note: the current temperature is not exact room temperature, just for reference.
3. Press standby button  to turn on or turn off the device.
4. Press mode button  to set speed of the device (ECO, Levels 1, 2, 3).
5. Press settings button  to set other functions (Timer, Child-lock etc.).

Screen settings

Settings

Child Lock ---- Press bar to activate / de-activate Child-lock mode.

dp_no_sound ---- Press bar to activate / de-activate Sound.

dp_on_timer 2 >---- Press button to make the Auto-on timer setting by "+ / -" from 1-24 hours.

dp_off_timer 0 >---- Press button to make the Auto-off timer setting by "+ / -" from 1-24 hours.


(Choose either 1-24 hours Auto-on or Auto-off timer settings)

Timer >---- Press button to make different time periods' Auto on/off timer setting




Timer settings

****Note: Weekly timer settings can only be arranged through the App.**

- Press the Add Schedule button to make the timer settings.
 - Choose the time.
 - Choose the day/days of the week you want to repeat the settings.
 - Write any note as your need.
 - Press the Notification bar to activate / de-activate the notification.
 - Press the Switch button to choose the Auto-on or Auto-off settings.
 - After finish all settings, please save it.
- * You can add different Auto-on or Auto-off timer settings. Then the heater will turn on or off as your setting time periods.



Troubleshooting

- * Check if the device is activated and in Stand-By mode. If not, activate it and press buttons    for about 5 seconds. When Wi-Fi function is activated, the Wi-Fi symbol on the screen will flash rapidly.
- * Make sure the Wi-Fi password has been typed correctly (capitals and / or lowercase letters considered as different).
- * Make sure your telephone is properly connected to Wi-Fi Network.
- * Make sure the network you use is 2.4GHz (Wi-Fi 5GHz network is not supported) and that your signal is strong enough.
- * Check your Wi-Fi router settings. The encryption must be WPA2-PSK and protocol must be AES.
- * If you cannot be connected with the fast connection guide, follow the instructions for connection and try with manual search.



KALLIOPI KARIDA & CO, LP

87A, 17is Noemvriou str.
P.C. 55535, Pylaia, Greece
Tel. +30 2316 006600
www.morris.gr